




WELCOME

In your luxury suite, the Cisco Unified IP Phone can be used to control the TVs and to place calls. It has a touch screen, softkeys (which vary depending on the phone model, screen contents, and your site's implementation), a navigation pad, and a phone keypad.



- 1 Use the **touch screen** to select the TVs or select a service.
TIP: Press the Services button  if services are not displayed.
- 2 Use the **softkeys** to:
 - Navigate.
 - Mute or unmute *all* TVs with single touch.
 - Turn on and off *all* TVs with single touch.
- 3 The **navigation pad** is not used with TV control services in Dynamic Signage Director.
- 4 Use the **keypad** to dial a phone number or enter a channel number.
- 5 Use the line buttons to select a phone line (if multiple), speed dial, or go to a defined URL.

CONTROLLING TVS

To control the TVs, touch **TV/Volume**.




SELECTING A DISPLAY

The TVs are typically identified by location. Touch the label of the TV you want to control or touch **All**.




SELECTING A CHANNEL

Touch desired channel, or touch the Page Up or Page Down arrows to see additional channels.



NOTE: The **Back** softkey will take you back to the previous operational screen. To scroll through multiple listing pages, use the Page Up or Down arrows.

As an alternative, you can touch **Guide** to view the channel guide on the associated TV, or touch **Keypad** and enter a desired channel number.



ADJUSTING THE VOLUME

To adjust the volume, touch the following buttons:



➤ To increase the volume on the selected TV(s).



➤ To decrease the volume on the selected TV(s).



➤ To toggle between mute and unmute on the selected TV(s).



USING ADVANCED FUNCTIONS

To access advanced functions such as controls for external inputs and closed captioning, touch **Advanced**.



TV Inputs

If the TV has been configured to allow external input devices, such as a DVD player or personal computer, the TV inputs list will display a listing of available sources. Touch the desired input.



Closed Captioning

Many of the available channels may provide closed captions that can be displayed on the TV. To turn closed captioning on (or off), touch **cc**.



NOTE: Depending on your configuration, there might be multiple Closed Captioning options.

PLACING A PHONE CALL

To place a phone call, simply pick up the handset and dial the desired number.

Alternatively, you can:

- Touch the Phone symbol on the touch screen and dial the number on the displayed touch panel.
- Touch the desired speed dial (availability may vary).



If the suite is equipped with multiple phone lines and you wish to place a call on a line other than the primary line, simply touch the line button associated with the desired line and dial the number using the keypad.

USING SOFTKEYS

The softkeys on the phone are located at the bottom of the touch screen and provide access to functions, which vary depending on the phone model and screen currently being displayed.

Softkey	Function
Advanced	Access the advanced features (external input, closed captioning) for the selected TV.
Back	Go back to the previous operational screen.
Guide	Display the channel guide on the designated TV.
Home or Close	Return to the home screen (Display Control).
Keypad	Select a channel by entering a number using the keypad.
Mute or UnMute	Mute or unmute the volume on all TVs.
Tv On or Tv Off	Turn power on or off for all TVs.
More	(9971 only) Displays additional softkeys.

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.

